



NO.	PARTS CODE	PARTS NAME	QT.	NO.	PARTS CODE	PARTS NAME	QT.
13	FEE290	REBOUND SPACER	1	1	FKA044	FIXING BOLT SET	2
14	FEE048-16	SUPPORT TUBE	1	2	FKE201	BOTTOM CASE ASSY	1
15	FEE047	SUPPORT PLATE	1	2f	FEE188	BOTTOM STOPPER	1
16	FSB044	SUPPORT BOLT	1	2g	FAA125-30	DUST SEAL	2
17	FKA022-20	PISTON UNIT	1	3	FEE189-10	FORK NOSE	1
18	FAA153	O RING	1	4	FKE178-90	UPPER ASSY	1
19	FEE328	AIR CAP	1	5	FEE359	REBOUND WASHER	1
20	FAA116	AIR VALVE	1	6	FEP052-10	REBOUND RUBBER	1
21	FAA118	VALVE CAP SEAL	1	7	FEE555-20	REBOUND SPRING GUIDE 3	1
22	FAA121-10	VALVE CAP	1	8	FEP307	REBOUND SPRING 2	1
23	FUN006-13	DAMPER UNIT	1	9	FEE555-10	REBOUND SPRING GUIDE 2	1
24	FKE028-21	LO TOP CAP ASSY	1	10	FEP306	REBOUND SPRING 1	1
25	FKA023	DYNAMO CABLE GUIDE SET	1	11	FEE555-00	REBOUND SPRING GUIDE 1	1
				12	FEE247-20	REBOUND SPACER	1